

Unit C, Furness Drive, Poulton Business Drive

1.00 Personnel Doors

- 1.01 Remove outer security sheeting and dispose of
- 1.02 Remove alarm wiring and connections and dispose of
- 1.03 Remove sliding bolts and wooden blocks from fire escape door and dispose of
- 1.04 Fill holes and sand down
- 1.05 Apply 2 coats undercoat
- 1.06 Apply 1 coat Oil based gloss (Brilliant white to exterior and Post Office Red to interior)

2.00 Steel stanchions (each side of main roller shutter door)

- 2.01 Sand down and where bare metal is exposed remove all rust.
- 2.02 Apply 2 coats Red Oxide metal paint.