

Unit C, Furness Drive, Poulton Business Drive

1.00 Personnel Door Replacement

1.01 Remove existing timber door and frame and dispose of.

1.02 Fit new inward opening uPVC door and frame with overhead solid panel and solid panel infill to door.

1.03 Seal around door after fitting.

1.04 Remove standard lock and leave on floor near to door

1.05 Fit toggle lock (toggle to inside)